



A2I+ A-GND A2I- ISI+ IB+ I-GND USI+ USI+ UB+ U-GND M2I+ M-GND M2I-

PE1ABR  
Q5-5050

AUDIO-S ANALYSER

FILE:  
AUDI-VOE

